



R1000 Rugby Goals

Assembly Instructions

Dimensions 32' Height (above ground) x 18'6" Width

Ground sleeves 3' deep sleeve (Aluminum pipe 3.5" ID)
Ground sleeve should be cemented in place

General recommendations for installation:

Please note that your specific conditions may affect these general guidelines.

- 1.) Hole center to hole center between ground sleeves is 225.5"
- 2.) Hole should be approx. 40" deep. Fill bottom 4" of hole with drainage gravel. Diameter of hole approx. 10". Wider if soil is soft.
- 3.) Place ground sleeve in hole with bolt facing the back of the field and the top flush with ground level.
- 4.) Cement in place, leaving the top 4" to fill with sand to leave bolt accessible.
- 5.) Slide upper upright into lower upright, install bolt. Assembled upright height 35'
- 6.) Using 3 or more people, stand upright straight up and insert in ground sleeve.
- 7.) Install crossbars from ladder on front side of goal.
- 8.) Tighten ground sleeve bolts.

Please do not hesitate to call if you experience any problems.

Ph. 888 726 7627 Ext.1

Email:sales@scoremaster.com

Fax 250 655 4334

Website:www.scoremaster.com